

SHOULDERING AND MOWING

1. PREPARATION

- a. Set up temporary traffic control devices as necessary according to part VI of the Manual on Uniform Traffic Control Devices (MUTCD).

2. PROCESS

- a. Place import material as needed and perform grading to achieve proper drainage.
- b. Mulch clippings to help reduce the amount of supplemental fertilizer required.

3. ACTIONS

- a. Clean any loose material off asphalt or gutter.

4. DOCUMENTATION

- a. Record location and date on the maintenance database and map.